


CKC

# L Par 18



[www.ckclighting.com](http://www.ckclighting.com)

## CKC LIGHTING CO.,LTD

Addr.:335 Nansha Avenue, Tung Chung Town,  
Nansha District, Guangzhou City, China.  
TEL: (020)3920 4506 FAX: (020)3920 4631  
WEB: [www.ckclighting.com](http://www.ckclighting.com)



Before carrying out any installation, maintenance, or cleaning of the lighting fixtures, please confirm that the power has been cut off! Before using this fixture, please read this manual. Our company reserves the right to change product design and specifications without prior notice.

# CONTENTS

<b>1. Security Warning Information</b>	1
<b>2. Product Introduction</b>	3
2.1 Exterior dimensions	3
2.2 Fixture packaging accessories	3
<b>3. Main technical parameters of the equipment</b>	3
<b>4. Packaging and transportation</b>	4
4.1 Disassemble packaging	4
4.2 Equipment installation	4
<b>5. Installation Requirements Explanation</b>	5
5.1 Clamp installation	5
5.2 Fixture installtion	6
5.3 Hanging Installation Diagram	6
<b>6. Power and signal connection</b>	6
6.1 Power and signal socket	6
6.2 Power Connect	7
6.3 Signal Connect	7
<b>7. Control panel</b>	8
7.1 Panel Introduction	8
7.2 System menu	8
<b>8. DMX control channel table</b>	10
<b>9. Control circuit diagram</b>	14
<b>10. Regular maintenance</b>	14
10.1 Cleaning and maintenance	14
10.2 Fault analysis and handling	15

# ★ Statement ★

- This manual contains important information on safe use and installation. Please read it carefully and follow the requirements for operation and installation. Please keep this manual properly;
- The equipment has good performance and complete packaging when it leaves the factory. The operator should strictly follow the warning items and operating instructions stated in the manual. Any malfunction or damage caused by misuse or neglect of the manual is not within the scope of our company's responsibility and warranty;
- The relevant information in this manual is for reference only. All lighting products are subject to the actual product. Any changes will not be notified separately, and our company reserves the right of final interpretation.

## 1. Security Warning Information



### Attention !

Please read the safety requirements information in this section carefully before installing, powering on, operating, or repairing the lighting fixtures.



- This product is for professional use and is not suitable for other purposes;
- After receiving the lighting fixtures, please check if the packaging is complete and unpack to check if the equipment has been damaged due to transportation. If there is any damage caused by transportation, please do not use this lamp and contact local technicians or manufacturers as soon as possible;
- When transporting again, please use the original packaging materials;
- If there is obvious damage to the machine casing, it should be replaced in a timely manner;
- When hanging lamps, it is necessary to verify that the hanging equipment can withstand more than 6 times the weight of the lamp. After installation, it is necessary to verify that the lamp cover and installation buckle are secure and undamaged. At the same time, a safety rope should be used as an auxiliary safety for the lamp and fixed on the truss;
- The light source inside this luminaire should be replaced by the manufacturer, its service agent, or a similarly qualified person;
- If you have any other questions about how to safely operate the equipment, please contact our technical personnel or call our service hotline;
- This product has a protection level of IP65 and can be used both indoors and outdoors;



- Lighting fixtures should be kept clean and avoid prolonged use in overheated or dusty environments to prevent contact with chemical liquids;
- When using the product, attention should be paid to avoiding serious or fatal injuries caused by fire, heat, electrical shock, and ultraviolet radiation. Before powering on or installing, read the instruction manual first. Follow the safety precautions for operation and pay attention to the warning signs on the instructions and equipment;
- Only professionals are allowed to install, operate, and maintain lighting fixtures, and strictly follow the procedures stated in the operating instructions.



- The eyes cannot directly look at the luminous object;
- Do not connect this device to any dimmer;
- If visible damage occurs to the protective casing, lens, and display screen on the lighting fixture, it is considered as damage to the point of loss;
- Please do not place any filters or other items at the light outlet, and do not replace non original parts;
- The minimum safe illumination distance of the lamp is 1m.



- Before installation, please confirm that the power supply voltage used matches the voltage indicated on the light fixture. Each lighting fixture should be properly grounded and electrically installed according to relevant standards;
- Please disconnect the power before repairing or cleaning the equipment;
- During the operation of the lighting fixtures, touching the wires is prohibited to prevent electric shock;
- If the external soft cable or wire of this lamp is damaged, the wire should be replaced by the manufacturer, its agent, or a similarly qualified person to avoid danger;
- Avoid flammable liquids, water, or metal conductors from entering the interior of the lamp to prevent electric shock or fire. If any foreign objects enter the lamp, immediately cut off the power supply;
- When multiple lamps are operated in series, the signal lines can be connected in multiple ways, but the power supply must be connected separately.



- The lighting fixtures work normally at -20 °C to 45 °C . When replacing any components or accessories in the equipment, ensure that the power is disconnected to prevent electric shock and injury;
- The maximum surface temperature of the lamp during operation can reach 77 °C , please do not touch it with bare hands.




- The lighting fixtures must be installed in a sufficiently ventilated area, at least 0.5m away from adjacent surfaces, to ensure that no ventilation holes are blocked;
- Do not install the lighting fixtures directly on flammable objects;
- The minimum distance between all outer surfaces of the lamp and combustible materials is 0.5m.

## 2. Product Introduction


### 2.1 Exterior dimensions of lighting fixtures

338 × 198 × 328 mm



### 2.2 Packaging accessories

Name	QTY
Safety cable	1 PCS



## 3. Main technical parameters of the equipment

Product execution standards: GB7000.1-2023, GB7000.217-2023, Q/YF-2017

### ● Electrical parameter

Rated input voltage: AC 100V-240V~ 50Hz/60Hz

Rated power: 367 W

Power factor: 0.999F

Input Current: 1.75A 220V

### ● Source lifespan

> 20000 hours

### ● Optical system

Source: 18 × 20W RGB LED

Output luminous flux: 11050 Lm

Beam angel: 10°

Field angle: 20°

CCT: 2700 ~ 6500 K

CRI: 80


### ● Control and programming

Control channel: 4CH/7CH/8CH/10CH/13CH/16CH

Protocol: DMX512, RDM

Data connect: 3 pin or 5pin signal in/out

### ● Illumination draw



### ● Other effect function

Fast electronic strobe: 1~25Hz

LED refresh frequency: 900Hz-25KHz

### ● Other features and functions

Weight: 7.1 KG

## 4. Packaging and transportation

### 4.1 Disassemble packaging



Notice: After receiving the fixture, please unpack and check for any damage caused by transportation. If there is any damage caused by transportation, please do not use this fixture and contact the local technical personnel or manufacturer as soon as possible.

### 4.2 Equipment packaging


1). Disconnect the power supply before packaging the lighting fixtures to allow them to cool completely;

2). Flight cases can only be stacked in two layers and are not allowed to be reversed.

## 5. Installation Requirements Explanation

### 5.1 Clamp install



The lighting fixtures can be installed on the stage or on any direction of the truss, and the clamp can be quickly and easily locked onto the truss.



#### Waining !

Fixture can be used to fix the equipment, and a safety rope must be connected to the safety hook. Note that it cannot be connected to the handle.


#### Quick lock and clamp install



### 5.2 Equipment installation

- 1). Before installation, it is necessary to verify that the lamp hook and safety rope are not damaged, and that the installation object can withstand 6 times the total weight of the lamp and cable accessories;
- 2). Install the lamp hook on the handle and insert it horizontally into the handle mounting hole to lock it in place.


### 5.3 Hanging Installation Diagram




## 6. Power, Signal connect

### 6.1 Power and signal socket

1. Dmx input
2. Dmx output
3. Breathable valve
4. Power output
5. Power input



## 6.2 Power connect




This product uses Powercon In/Out to connect power cords. Due to power limitations, a 2 square meter power cord can carry up to 5 products at 220V and 2 product at 110V.


### Warning !

- Do not connect too many fixtures or overload a single power cord;
- Do not use power cords with damaged insulation layers, and do not place power cords on other wires;
- When the fixture is not in use or cleaned, please unplug the power cord; Do not forcefully unplug or drag the power cord directly.



## 6.3 Signal connect



The lighting fixtures are equipped with standard DMX XLR input and output sockets. Please use DMX512 shielded twisted pair signal cables or Category 3/5 or above network twisted pair cables for connection. The typical connection distance for DMX signal lines is 150 meters. When transmitting signals over long distances, a DMX512 signal amplifier must be added.




Connect a shielded twisted pair signal cable from the DMX output port of the controller to the DMX input port of the first device, and from the DMX output port of the first device to the DMX input port of the second device, and so on, until all the lamps are connected. Then install a terminal plug on the last 3 pin socket of each connected lamp output. (Weld a 4/1W, 120 Ω resistor between the 2 and 3 pins of a 3 or 5 core pin XLR plug).



## 7. Control panel

### 7.1 Panel Introduction

- Adopting OLED screen display;
- Press the MODE key to view or modify the lighting function settings, and press the UP, DOWN, LEFT, and RIGHT keys to select the function menu;
- Press the ENTER key to confirm your selected function menu, which will take you to the corresponding sub menu in the menu. Each menu item represents a specific function of the lighting fixture (as shown in the table below);
- Press the ENTER key to save your modifications or enter a submenu, and press the UP or DOWN key to modify values (increase or decrease values); Press the MODE key to return to the previous menu or exit.
- Press the MODE key to return to the previous menu or exit.



### 7.2. System menu

Note: The gray color block is the default setting value

Update Wait...

CKC

V1.01

Menu DMX Set	Address	001~512
	DMX Set	4CH/7CH/8CH/10CH/13CH/16CH
	NO DMX	Hold/Blackout/ Program
	Master	ON/OFF
	Slave	ON/OFF
		Auto
	Fan Set	High Silent

<b>Menu Function</b>	Dim Mode	Standard						
		Stage						
		TV						
		Architec						
		Theatre						
	LEDRfrsh	Stage 2						
		0.1s						
		.						
		.						
		10.0s						
<b>Menu Manual</b>	DimCurve	900/1000/1100/1200/1300/1400/1500/						
		2500/4000/5000/10k/15k/20k/25k Hz						
		(1200Hz)						
		Square						
		Linear						
	Display	Inv.Squa						
		S-Curve						
		SaveDlay	OFF/1~10					
		Lock	ON/ON1/OFF					
		Service	Password:11					
<b>Menu Program</b>	Prog 01	Red: 000-255						
		Green: 000-255						
		Blue: 000-255						
		Lime: 000-255						
		Strobe: 000-255						
	Prog 02	Dimmer: 000-255						
		ClrMacro: 00-64						
		ClrTemp: 000-255						
		Speed:000-255						
		Fade: 000-255						
<b>Menu Info</b>	Time Info	Prog 07	Speed:000-255					
			Fade: 000-255					
		...						
	Temp Info	Prog 01	Speed:000-255					
			Fade: 000-255					
		Prog 02	Speed:000-255					
			Fade: 000-255					
	DMX Valu	Prog 03	Speed:000-255					
			Fade: 000-255					
		Prog 04	Speed:000-255					
			Fade: 000-255					

		L:000-255
		...
Software	1U	V101

### 8. DMX channel table:


Channel Modes						Value	Function
4Ch	7Ch	8Ch	10Ch	13Ch	16Ch		
1	1	1	1	1	1	0-255	<b>Red</b>
		2					0~100%
2	2	3	2	2	2	0-255	<b>Green</b>
		4					0~100%
3	3	5	3	3	3	0-255	<b>Blue</b>
		6					0~100%
4	4	7	4	4	4	0-255	<b>Lime</b>
		8					0~100%
		5	5	5			Color Macros
		6	6	6	0-255		<b>Color Temperature 2700-7000K Linear</b>
							0~100%
							<b>Color Temperature Macros</b>
			0				Off
			001-054				2700k
			055-109				3200k
			110-164				4000k
			165-219				5600k
			220-255				6500k
							<b>Shutter, Strobe</b>
			0-31				Led's Off
			32-63				Led's On
			64-95				Strobe effect slow to fast
			96-127				Led's On
			128-159				Pulse-effect in sequences
			160-191				Led's On
			192-223				Random strobe effect slow to fast
			224-255				Led's On
		6	9	9	0-255		<b>Dimmer (Intensity)</b>
							Intensity 0 to 100%
		7	10	10	0-255		Dimmer Fine 16-bit
							<b>Auto programs:</b>

				0-31	Off
				32-63	Auto Program 1
				64-95	Auto Program 2
				96-127	Auto Program 3
				128-159	Auto Program 4
				160-191	Auto Program 5
				192-223	Auto Program 6
				224-255	Auto Program 7
			12	0-255	<b>Auto Programs Speed:</b> Slow to Fast speed
			13	0-255	<b>Auto Programs Fade:</b> Less to More
					<b>Dim Mode</b>
				0-20	Default to Unit Setting
				21-40	Standard
				41-60	Stage
				61-80	TV
				81-100	Architectural
				101-120	Theatre
				121-140	Stage 2
				141-160	Dim Speed from Fast to Slow (0.1-10s)
				161-255	Default to Unit Setting
					<b>Dim Curves (Hold 3s)</b>
				0-20	Square
				21-40	Linear
				41-60	Inv. Squa
				61-80	S.Curve
				81-255	No Function
					<b>Refresh Rates (Hold 3s)</b>
				0-15	Default to Unit Setting
				16-30	900HZ
				31-45	1000HZ
				46-60	1100HZ
				61-75	1200HZ
				76-90	1300HZ
				91-105	1400HZ
				106-120	1500HZ
				121-135	2500HZ
				136-150	4000HZ
				151-165	5000HZ
				166-180	10000HZ
				181-195	15000HZ
				196-210	20000HZ
				211-225	25000HZ
				226-255	No Function

Static colors sheet

	DMX VALUES	R	G	B	L
	0	OFF			
1	1-4	80	255	234	80
2	5-8	80	255	164	80
3	9-12	77	255	112	77
4	13-16	117	255	83	83
5	17-20	160	255	77	77
6	21-24	223	255	83	83
7	25-28	255	243	77	77
8	29-32	255	200	74	74
9	33-36	255	166	77	77
10	37-40	255	125	74	74
11	41-44	255	97	77	74
12	45-48	255	71	77	71
13	49-52	255	83	134	83
14	53-56	255	93	182	93
15	57-60	255	96	236	96
16	61-64	238	93	255	93
17	65-68	196	87	255	87
18	69-72	150	90	255	90
19	73-76	100	77	255	77
20	77-80	77	100	255	77
21	81-84	67	148	255	67
22	85-88	77	195	255	77
23	89-92	77	234	255	77
24	93-96	158	255	144	144
25	97-100	255	251	153	153
26	101-104	255	175	147	147
27	105-108	255	138	186	138
28	109-112	255	147	251	147
29	113-116	151	138	255	138
30	117-120	99	0	255	100
31	121-124	138	169	255	138
32	125-128	255	255	255	255

## 9. Control circuit diagram



## 10. Regular maintenance

### 10.1 Cleaning and maintenance

Lighting fixtures require daily cleaning and maintenance, and their service life largely depends on the operating environment and standards. If you have any questions, please consult our technical engineers for advice. Maintenance and repair work not included in this book should be entrusted to our qualified technical engineers.

**Attention!** Damage caused by dust, e-liquid, or other reasons, as well as abnormal use, is not covered by the warranty.



### Warning !

Before opening any lid, disconnect the power supply. Cleaning optical components requires gentle wiping as the coating surface is prone to scratching. Do not use damaging liquids or hard objects, as they may damage the plastic or coating surface.

- When the lens is cracked or otherwise damaged, it should be replaced in a timely manner;
- When the brightness significantly decreases, the LED may have reached its expiration date and should be replaced in a timely manner;
- When the fixture cannot start, please check if the fixture power fuse is blown. If it is blown, a fuse of the same specification must be used for installation;
- The fixture is equipped with a temperature protection device. When the temperature is too high, the protection device will automatically reduce power.
- When this situation occurs, please check whether the fan is running normally, whether the fan and fan mesh are clogged with dust, identify the fault and repair it before starting the fixture. Please note that only qualified technicians are allowed to carry out maintenance work;
- To maintain smooth movement of the focusing lens, it is recommended to lubricate the guide rail of the focusing lens every three months. Excellent and high-temperature resistant lubricating grease should be used, and excessive grease should not be used as it can easily dirty adjacent components.

### 10.2 Fault analysis and handling

Fault description	Analysis	Processing method
No action after power on	Check if the power switch is turned on	Turn on
	Check if the fuse is blown	Replace
	Check if the output of PSU is normal	Detecting voltage
	Check if poor contact in the internal circuit	Reconnect
Uncontrolled lighting fixtures	Check if the DMX signal cable is connected correctly (If there is no signal, the display screen will flash)	Reconnect or replace
	Check if the address code is correct and if the DMX mode of the lighting fixture matches the settings	Reconfirm
	The main control PCB is damaged	Replace
Not bright	LED aging or damage	Replace
	Power PCB malfunction	Check/ Replace
	Loose or poor contact of the circuit	Reconnect
	PSU malfunction	Replace
Automatically turn off or dim the lights	LED aging	Replace
	The temperature control switch is damaged	Replace

Weak light efficiency and uneven light spot	LED aging	Replace
	The optical mirror has accumulated dust or stains	Clean
	The optical mirror is damaged	Replace
Impure color	Weakening of light efficiency	Replace led PCB
	The color filter has accumulated dust or stains	Clean
	The color filter has been demolded or damaged	Replace
<b>Attention!</b> The above analysis is for abnormal reference only. Non professionals are not allowed to disassemble and repair the machine		

